

GENERAL


EURO CONNECTOR PARTS BREAKDOWN

This Bulletin provides a breakdown of the parts which make up the Euro connector used in all current wirefeeders except W19.

WF007

used in:

- CP115, CP116, CP111 (Weldmatic 150, 175, 215)
- W53, W54, and W55 wirefeeders (215 external, 255 & 2RD)




QUALITY WELDING PRODUCTS, SYSTEMS AND SERVICES

The information provided in this sheet is accurate and reliable, however no warranty of accuracy or reliability is given and no responsibility arising in any other ways by errors or omissions is accepted. Any information involving mains or high voltage is intended for use by qualified electrical personnel only.

WF007-1

used in W56 (4RD) wirefeeders



Hugh Stewart,
Technical Service Coordinator